


## How to use the keypad:



### Heating Modes:

- ☀ Comfort – (press + and – buttons to adjust temperature)
- ❄ Frost Protection – (press + and – buttons to adjust temperature)
- 🌙 Economy – (always a set number of degrees lower than Comfort)
- AUTO Program


## Setting the time:

1. Press to enter standby mode.
2. Press to go to the time screen.
3. The days will flash. Choose 1-7, where 1 is Monday and so on.
4. Press OK.
5. The hour will flash. Use the – and + keys to select the hour.
6. Press OK.
7. The minutes will flash. Use the – and + keys to select the hour.
8. Press OK.
9. Press to return to standby mode.
10. Press again to go back to heating modes.


## Setting a Program:

First, navigate to the program screen:

1. Press to leave standby mode
2. Press until you reach program mode:
3. Press PROG to edit the program.



### How the program works:




The program allows you to assign a heating mode to every hour of every day of the week.

The numbers on the right indicate which day you're programming: 1 for Monday, 2 for Tuesday, and so on.

The blocks across the hours of the day show which modes are set to which hour:

- 2 bars = comfort mode
- 1 bar = economy mode
- 0 bars = frost mode



To set your program, use the ☀ (comfort), 🌙 (economy) and ❄ (frost protection) buttons to populate each hour with a heating mode. You will see the blocks change as you go, overwriting the original program.

You can cycle through the 1<sup>st</sup> day pressing the mode buttons until you're happy with Monday's program. Press OK to move onto the next day. Repeat the steps above for each day. When you press OK on the 7<sup>th</sup> day, the radiator will start heating as per your program.